




CUT CORNER

## GUE VALVE DRILL

1. Signal your intent to do a valve drill.
2. Purge the backup regulator to verify operation.
3. Shutdown right post, breath down the longhose and switch to the backup regulator. 
4. Clip the longhose second stage to the right chest D-ring.
5. Re-open the right post, unclip the 2. stage and purge to verify operation.
6. Switch to the longhose regulator.
7. Close and then reopen the isolator. 
8. Switch light to the right hand.
9. Shutdown the left post, then purge the backup regulator. 
10. Re-open the left post.
11. Purge the backup regulator to check it works.
12. Return the light to the left hand.
13. Conduct a flow check to ensure all valves are open.
14. Signal that the drill is over.

version 1.3



Copyright © 2010 Rune Henssel. All Rights Reserved. [www.frogkick.dk](http://www.frogkick.dk)